



Insignia NS-B4111 Casing Replacement

Prerequisite Only.

Written By: Kristin Yoshioka






TOOLS:


- [26 Bit Driver Kit](#) (1)
-

Step 1 — Casing



- Turn the boombox upside down again. With the Phillips PH1 or the Flathead #3 screwdriver, remove the three 14mm black screws.
- Remove the four 18mm chrome screws with the Phillips PH1 screwdriver.

Step 2



- Gently remove the bottom half of the casing from the top half of the casing.

i The antenna base is connected to the motherboard by a red wire. This wire will prevent the two halves from separating completely.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 07:11:41 AM.